


HID PATIENT FOCUSED INSTALLATION INSTRUCTIONS



1

Using provided suction cup, gently remove acrylic lens and paper graphic insert if present.

2

Slide out the top and bottom tabs to reveal the slots for mounting. Use a level to place the system to its intended location and mark the slot location. Refer to ADA requirements if applicable.

3

Using the marks from step 3, install the appropriate screw anchors. **You must use flat head (countersunk) screws, no larger than #6.**

4

Using flat head (countersunk) screws, **no larger than #6**, affix sign system to wall.

5

CAUTION:

Ensure the screw heads are flush with the slots, allowing the tabs to slide unobstructed.

6

Slide the tabs closed, then reassemble the acrylic lens and paper insert if present.

